


## Door Preparation Instructions for Door **with Existing Holes**

Schlage Encode™, BE489

### Tools Needed

① **If you are uncomfortable performing these steps, call a locksmith for assistance.**




### 1 Measure door thickness.

If the door is thinner than 1 3/8" or thicker than 1 3/4", then the lock will not fit properly on the door.


A thick door kit is used to fit the Schlage Encode to doors that are between 1 7/8" and 2 1/4" thick.

① **A thick door kit is available from Product Support at (888) 805-9837**




### 2 Measure the backset.

If existing backset is not 2 3/8" or 2 3/4", then the lock will not fit properly on the door.




### 3 Measure the hole sizes.


3a If hole sizes are larger than those shown, then the lock will not fit properly on the door. If hole sizes are smaller than those shown, see steps 3b and 3c.



3b If necessary, enlarge hole in door face.




3c If necessary, enlarge hole in door edge.




## 4 Check the door jamb.


- 4a Place new strike and reinforcement plate against the door jamb. If these do not fit properly, see steps **4b** and **4c**.



- 4b If correction is necessary, trace faceplate and mark holes.



- 4c If necessary, use chisel, hammer and drill to correct door jamb preparation.



Questions about your new  
Schlage **Encode**™ Smart WiFi Deadbolt?

**Please don't return it to the store!**

Let us help you first!



[www.schlage.com/faqs-encode](http://www.schlage.com/faqs-encode)

**Schlage Customer Service**  
Calling From:  
USA: (888) 805-9837  
Canada: (800) 997-4734  
México: 018005067866



© Allegion 2018  
Schlage Encode door prep with holes  
Rev. 10/18-a